

Quick Installation Instructions

Philmac Poly to UTC

Vinidex
by aliaxis

Philmac[®]

by aliaxis



1. Cut Pipe to Length

The fitting is pre-assembled and ready to use. Cut pipe square and to length using the flange on the central body as a guide. Ensure the end of connecting pipe is undamaged and clean.



2. Ready to Use Position

To ensure adequate insertion depth, witness mark the pipe to the back of the flange. If conditions permit a marker pen can be used or alternatively use of a thumb is suitable.



3. Pipe Insertion

Insert the pipe to the correct depth. Always ensure the nut is backed off and 3 threads are showing. Pipes at the top end of the fitting tolerance may require 5 threads showing.



4. Nut Tightening

Tighten nut firmly with a wrench. Nut will not butt against the body flange when the pipe size is at the top end of the fitting tolerance.



5. Fully Installed

The fitting is fully installed when the nut cannot be tightened any further with reasonable force.



6. Disassembly

Unscrew the nut with a wrench. Pipe will be released and can be pulled out of the fitting.

Note: Installation instructions apply to the UTC[®] end of a 3G x UTC[®] fitting or the UTC[®] ends of a UTC[®] x UTC[®] fitting.

P 13 11 69 | sales@vinidex.com.au | www.vinidex.com.au

Limitation of Liability

This information has been compiled by Vinidex Pty Limited ("the Company") to promote better understanding of the technical aspects of the Company's products to assist users in obtaining from them the best possible performance. The information is supplied subject to acknowledgement of the following conditions: 1 The information is protected by copyright and may not be copied or reproduced in any form or by any means in whole or in part without prior consent in writing by the Company. 2 Product specifications, usage data and advisory information may change from time to time with advances in research and field experience. The Company reserves the right to make such changes at any time without further notice. 3 Correct usage of the Company's products involves engineering judgements, which can not be properly made without full knowledge of all the conditions pertaining to each specific installation. The Company expressly disclaims all and any liability to any person whether supplied with this publication or not in respect of anything and all of the consequences of anything done or omitted to be done by any such person in reliance whether whole or part of the contents of this publication. 4 No offer to trade, nor any conditions of trading, are expressed or implied by the issue of content of this information. Nothing herein shall override the Company's Condition of Sale, which may be obtained from the Registered Office or any Sales Office of the Company. 5 This information is and shall remain the property of the Company, and shall be surrendered on demand to the Company. 6 Information supplied in this information does not override a job specification, where such conflict arises; consult the authority supervising the job.

VIN341E
20190507