## **Quick Installation Guide**

Philmac Poly to Copper



## **Philmac**°

## by aliaxis



 Cut PE or poly pipe square and insert until pipe stop is felt.



2. Tighten the nut by hand ensuring the nut flange is touching the fitting body, use a wrench if neccessary.



3. Cut copper pipe square. The fittings is pre-assembled and ready to use. Mark the depth of copper insertaion using 'pipe stop' marking or body flange as visual indicator. Remove any scale or burrs from the copper pipe.



4. Insert the copper pipe and push into the rubber seal up to the mark indicator



5. Tighten the nut by hand and finish using a wrench. Remember to check that the nut is tight against the body flange.



6. Remember to replace the stainless steel grip ring if re-using the copper connection.

P 13 11 69 | sales@vinidex.com.au | www.vinidex.com.au

This information has been compiled by Vinidex Pty Limited ("the Company") to promote better understanding of the technical aspects of the Company's products to assist users in obtaining from them the best possible performance. The information is supplied a subject to acknowledgment of the following conditions:

1 The information is protected by copyright and may not be copied or reproduced in any form or by any means in whole or in part without prior consent in writing by the Company. 2 Product specifications, usage data and advisory information may change from time to time with advances in research and field experience. The Company reserves the pit to make such changes at any time without further notice. 3 Correct usage of the Company's products involves engineering judgments, which can not be properly made without full knowledge of all the conditions pertaining to each specific installation. The Company expressly disclaims all and any liability to any person whether supplied with this publication or not in respect of anything and all of the consequences of anything done or omitted to be done by any such person in reliance whether whole or part of the contents of this publication. 4 No offer to trade, nor any conditions of strading, are expressed or implied by the issue of content of this information. Nothing herein shall override the Company's Condition of Sale, which may be obtained from the Registered Office or any Sales Office of the Company. 5 This information is and shall remain the property of the Company, and shall be surrendered on demand to the Company, 6 Information supplied in this information does not override a job specification, where such conflict arises; consult the authority supervising the job.

VIN341D

20196507